



Thank you for your purchase of your Caroline's Treasures Garden Flag that was proudly Made in the USA!

INSTALLATION GUIDE / Assembly Instructions:

This garden flag has been sewn with a "Sleeve Pole Pocket" at the top of the flag.

Place your new garden size flag next to the garden stand at the top of the stand (sold separately) Use your fingers to thread the flag over the top portion of the garden stand. Your flag should hang below the top of the stand.

Replacement parts list:

There are no replacement parts for this item.

Use and Care Instructions:

Your Caroline's Treasures Garden Flag is weather resistant. If your flag becomes dusty or dirty, you may wash your flag separately in your home washing machine. Please remove your flag from your garden stand before placing it in your washer. Please do not bleach.



This is how your flag should look once it is placed properly on the garden stand.

Remember to change out your flags with the seasons and to make an artistic statement in your garden or in your yard.

Thanks again for your purchase!

Please call (251) 473-6882 with any questions